

**OWL LABS®**

# EXPANSION MIC

## for Meeting Owl® 3


Extend the audio range of your Meeting Owl 3 by by 8 feet (2.5 meters) in the direction of the mic, so all voices are heard.

### KEY BENEFITS

- Ensure that the Meeting Owl 3 hears voices that are quieter or further away by extending the audio pick-up range from 18ft to 26ft in the direction of the mic.
- Keep the conversation flowing easily for participants further from the Meeting Owl 3 by putting a mute button at their fingertips.
- Designed to work exclusively with the Meeting Owl 3 for optimal performance and complementary design. Not compatible with Meeting Owl Pro or Original.
- Connects to the Meeting Owl 3 using a micro-HDMI to micro-HDMI cable.
- Includes mounting bracket with adhesive strips and screws for more confident and secure installation.



Works with the Meeting Owl 3



### FROM OWL LABS, FEATURED IN

The New York Times

WSJ



WIRED

Forbes

FAST COMPANY

The Boston Globe


INSIDER



Learn More


## Expansion Mic setup is simple

1




Remove the expansion port cover on the Meeting Owl. Then plug the cable into the Expansion Mic and the Meeting Owl.

2




Place the Expansion Mic at least 6 feet (1.8m) away from the Meeting Owl. The Meeting Owl should be at least 18 inches (0.5m) from the monitor/TV.

3



Move the Expansion Mic so it's facing away from the Meeting Owl. Position it so the microphone is facing where people will be speaking.

## How it works



“

“The Meeting Owl has completely transformed our ability to work well across our team and our organization.”

— RORY SUTHERLAND, VICE CHAIRMAN, OGILVY

[READ CASE STUDY](#)

Learn More